


C1015(C1014)

3/8" (1/2") AIR RATCHET WRENCH



PARTS LIST

No.	Parts No.	Description	Q'ty
1	c1014-01	Ratchet Yoke	1
2	c1014-02	Drive Bushing	1
3	c1014-03	Crank Shaft	1
4	c1014-04	Ratchet Housing	1
5	c1015-05	Reverse Button [c1015]	1
	c1014-05	Reverse Button [c1014]	1
6	c1014-06	Ratchet Spring	1
7	c1014-07	Spring Cap	1
8	c1014-08	Washer	1
9	c1015-09	3/8" Ratchet Anvil [c1015]	1
	c1014-09	1/2" Ratchet Anvil [C1014]	1
10	c1014-10	Spring Pin (Φ2.5x6)	1
11	c1014-11	Pawl	1
12	c1014-12	Needle Roller	1
13	c1014-13	Steel Ball [ST-c1014]	1
	c1015-13	Steel Ball [c1015]	1
14	c1014-14	Friction Spring	2
15	c1014-15	STeel Ball (5/32")	2
16	c1015-16	Trust Washer [c1015]	1
	c1014-16	Trust Washer [c1014]	1
17	c1014-17	internal Stop Ring (R29)	1
18	c1014-18	Clamp Nut	1
19	c1014-19	Needle Bearing (HK1212)	1
20	c1014-20	Bushing	1
21	c1014-21	Idler Spindle	1
22	c1014-22	Needle Roller	3

No.	Parts No.	Description	Q'ty
23	c1014-23	Idler Gear	3
24	c1014-24	Internal Gear	1
25	c1014-25	Ball Bearing (608ZZ)	1
26	c1014-26	Front End Plate	1
27	c1014-27	Spring Pin (Φ2.5x5)	3
28	c1014-28	Spacer	1
29	c1014-29	Rotor	1
30	c1014-30	Rotor Blade	4
31	c1014-31	Cylinder	1
32	c1014-32	Rear End Plate	1
33	c1014-33	Ball Bearing (696ZZ)	1
34	c1014-34	Motor Housing	1
35	c1014-35A	Valve Screw -Plastic	1
	c1014-35B	Valve Screw -Brass (Option)	1
36	c1014-36	O-Ring (P10A)	1
37	c1014-37	Valve Spring	1
38	c1014-38	Throttle Valve	1
39	c1014-39	O-Ring (P4)	1
40	c1014-40	Valve Shaft	1
41	c1014-41	Spring Pin (Φ2.5x20)	1
42	c1014-42	Spring Pin (Φ3x22)	1
43	c1014-43	Safety Lever Ass'y	1
44	c1014-44	O-Ring (S22.4)	1
45	c1014-45	Exhaust Sleeve	1
46	c1014-46	Inlet Bushing	1
47	c1014-47	Housing Cover	1